

Secura Hard Sealer

1. PRODUCT DESCRIPTION

Special water-based polymer coating. Satin. For the care and refreshing of thoroughly cleaned or thoroughly cleaned non-absorbent floors. For professional use in public buildings.

- Protects the floor.
- Reduces dirt adhesion and the time needed for day-to-day maintenance.
- Regular cleaning of the protected surface is simplified. We recommend for this purpose: PU Cleaner / Floor Cleaner R1000
- Good resistance to shoe marks
- Slip-resistant care film. Suitable for routine cleaning of sports floors.
- Metal cross-linked polymer dispersion.
- High solid content.
- Suitable for care film renovation with high-speed process.

Suitable for closed-pored, non-absorbent surfaces.

- PVC / LVT
- Linoleum, if porous after priming with Lino Primer.
- Lacquered wooden floors
- The application on PU/EP cast floorings, polyolefin, rubber and stone floors has to be tested specifically in each project.

Please take note of our specific floor care guides under www.dr-schutz.com.

2. APPLICATION

Shake up well. Apply undiluted with the Dr. Schutz Polish Applicator or the Dr. Schutz Professional Mop at a minimum of 15 °C in an even, thin film to the surface in the direction of installation, after it has been thoroughly or thoroughly cleaned and dried. For increased protection, repeat the application when the care film is resistant to foot traffic.

Please note:

- Avoid strong sunlight and draughts during application.
- Switch off under-floor heating well in advance.

3. CONSUMPTION

25-30 g/m² per application (coverage: 30-40 m²/l)

4. DRYING TIME

Can be carefully walked on, or worked on again after the water has evaporated (30-60 minutes) . Can be used with caution 12 hours after the last layer has dried.

Secura Hard Sealer

Please note:

- Low temperatures, increased air humidity and poor ventilation can significantly extend the drying time.
- The evaporation of water can be accelerated by ventilation. We recommend our Dr. Schutz TG1 drying fan.

5. STORAGE

Protect from frost. Store in a cool dry place. Keep out of the reach of children.

6. TECHNICAL DATA

Ingredients: water / polyacrylate / polyurethane / glycol ether / silicic acids / waxes / additives / perfumes TETRAMETHYL ACETYLOCTAHYDRONAPHTHALENES / preservation agents BRONOPOL BENZISOTHIAZOLINONE METHYLISOTHIAZOLINONE METHYLCHLOROISOTHIAZOLINONE / Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2-methyl-2H-isothiazol-3-one (3:1), 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction.

GISCODE GE10 (Emulsions/Dispersions) (Germany)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: no labelling obligation. UFI: CFJ0-W0VM-Q00G-36D7

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

7. SPECIAL NOTES

- All indications based on 23°C/50% rH/ 3-fold change of air per hour. Existing conditions can vary and account for different results.
- Please pay attention to the printed batch number. Only use products with the same batch number in one layer. In the case of different batches, mix these in a separate container before using.
- Matt care films may tend to leave smudge marks due to the application. In case of doubt, a sample application is recommended.
- Avoid excessive application of care products that darken due to prolonged use.
Used, dirty or damaged care layers should be removed regularly by intensive stripping. We recommend for this: Clean&Strip / Turbo Strip /
- Super Basic Cleaner . The protection of the floor is maintained when the floor is re-treated after a stripping. The maintenance cycle is based on the degree of wear.

8. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz surface products.
- Safety Data Sheet available on request.

Secura Hard Sealer

www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.

Dr. Schutz - We Care About Floors

Headquarter (international)
Germany

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

phone +49 (228) 95352-40
fax +49 (228) 95352-46
email: export@dr-schutz.com
www.dr-schutz.com

United Kingdom

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP
United Kingdom

contact: Richard Nelson
phone +44 (1296) 437827
fax +44 (1296) 334219
email: richard@drschutz.co.uk

Ireland

Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork
T12 R9F9
Republic of Ireland

contact: Paul O'Reardon
mobile +353 87 767 8388
email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.